

DIGITAL STRIKE COUNTER INSTRUCTIONS

? DIGITAL STRIKE COUNTER:

You are about to install a DIGITAL STRIKE COUNTER on your Automatic Resetting Kill Trap.

Your DIGITAL STRIKE COUNTER will collect the number of strikes the trap has delivered in the intervals between checks and trap maintenance. If this is your first time installing a DIGITAL STRIKE COUNTER please take the time to read these instructions to get the optimum performance from your device.

To ensure your trap remains active the CO2 CANISTER in your Goodnature Automatic Traps should be replaced every 6 months regardless of the number of pests. For further details on maintaining your Goodnature Automatic Traps please refer to the trap handbook.

STRIKE COUNTER PARTS:



NEW ZEALAND

goodnature.co.nz

Goodnature Limited
4-12 Cruickshank St
Kilbirnie, Wellington 6022
New Zealand
p +64 4 387 3872

1 INSTALLATION:

Slide the soft rubber strap onto the CO2 CANISTER and wind it in the same direction as the CO2 CANISTER threads in to the POWER UNIT until the depression on the back-side of the DIGITAL STRIKE COUNTER and the CO2 CANISTER align.



2 ALIGN THE COUNTER:

Ensure the DIGITAL READ OUT and BUTTON surface faces toward the operator, directly away from the tree or post when installed.

This ensures accurate performance of the DIGITAL STRIKE COUNTER when the trap is activated.



3 RESET TO ZERO:

With the DIGITAL STRIKE COUNTER in place you can now reset the DIGITAL READ OUT to zero (00).

To do this firmly press and hold the BUTTON for 5 seconds. The DIGITAL READ OUT will awaken and then show 00.



4 CHECK YOUR STRIKES:

To check the recorded strikes briefly press the BUTTON and release.

The DIGITAL READ OUT will awaken and show the number of strikes recorded.



! WARRANTY:

We are dedicated to delivering a quality product to all our customers. All of our products are warranted for two years from date of purchase against defects in material and workmanship.

If we determine that the product has a manufacturing fault, we will repair or replace it free of charge to you. The decision to repair or replace is solely at the discretion of Goodnature.

Only the original owner is covered by the manufacturer's warranty and must have purchased the product from an authorised Goodnature dealer.

WHAT IS NOT COVERED UNDER WARRANTY?

Our manufacturing warranty does not cover claims resulting from misuse, abnormal use, or installation contrary to instructions, transportation damage (including airline or freight damage), dropped goods, negligence, second hand product, modified product (including use of CO2 canisters not supplied by Goodnature). Our warranty also does not cover corrosion to fasteners as a result of atmospheric or environmental conditions.

OUTSIDE OF WARRANTY TERMS?

If your product is outside the two year warranty period or if the fault is not covered by the manufacturer's warranty, we will happily repair your product where possible for a reasonable charge.

If your product is less than two years old and subject to a warranty claim please contact

hello@goodnature.co.nz



DESIGNED AND MADE IN
AOTEAROA, NEW ZEALAND